TELLDUS

QUICK GUIDE


Easy installation of your Telldus Z-Wave Mini Plugin Switch




CONNECTING YOU AND YOUR HOME

1. INCLUDE THE DEVICE IN TELLDUS LIVE


Lägga till enheten i Telldus Live • Inkludere enheten i Telldus Live • Das Gerät in Telldus Live einschließen • Laitteen liittäminen Telldus Live • Inkludere enheden i Telldus Live





1.3

live.telldus.com




1.4

live.telldus.com




1.5

live.telldus.com



Follow the built-in wizard • Följ den inbyggda guiden • Følg den innebygde veiviseren • Folgen Sie den Anweisungen des integrierten Assistenten • Seuraa sisäänrakennettua ohjattua asennusta • Følg den indbyggede vejledning

1.6



2. CONTROL THE DEVICE IN TELLDUS LIVE

Styra enheten i Telldus Live • Styre enheten i Telldus Live • Das Gerät in Telldus Live steuern • Laitteen ohjaaminen Telldus Live • Styring af enheden i Telldus Live

2.1

live.telldus.com

live.telldus.com 〉 My Devices



2.2


live.telldus.com



3. CONTROL THE DEVICE MANUALLY

Styra enheten manuellt • Styre enheten manuelt • Das Gerät manuell steuern • Laitteen ohjaaminen manuaalisesti • Manuel styring af enheden

3.1



4. EDIT THE DEVICE

Redigera enheten • Redigere enheten • Das Gerät bearbeiten • Muokkaa laitetta • Redigér enheden

4.1

live.telldus.com

a. live.telldus.com My Devices

b. My lamp



4.2

live.telldus.com

Edit device

5. EXCLUDE THE DEVICE

Exkludera enheten • Ekskluder enheten • Das Gerät ausschließen • Poista laite • Ekskludér enheden

5.1

live.telldus.com

a. live.telldus.com My Devices

b. My lamp



5.2

live.telldus.com

Edit device


5.1

live.telldus.com

Exclude device



5.1



TECHNICAL SPECIFICATIONS

Tekniska Specifikationer • Tekniske Spesifikasjoner • Technische Spezifikationen • Tekniset Tiedot • Tekniske Specifikationer

Product Name	Telldus Z-Wave Mini Plugin Switch
Type Number	TZWP-102
Function	On/Off, Energy Meter, Surge Protection
Voltage	230V~ 50Hz
Input Current	Max 10A
Max Load	2300W Resistive
Surge Protection	>1500V
Energy Metering Accuracy <100W	<±2W
Energy Metering Accuracy >100W	<±2%
Operating Ambience	0°C–25°C; 5%–90% RH
Button Function	Include/Exclude/Power/Reset
IP Class	IP20
Protocol	Z-Wave
Chip Version	500 Plus Series
Frequency	868.42MHz (EU)

Frequency range	868.0-868.6MHz & 869.7-870.0MHz
Transmitting Range	up to 30m (open air)
Pollution Degree	2
Maximum RF Output Power	1dBm
Rated Impulse Withstand Voltage	2.5KV
Duty-type	S1, Continuous duty
Number of Operating Cycles	10000
Circuit Disconnection	Micro-disconnection
Glow-wire Temperature	650°C
Non-replaceable Built-in Protection	Thermal Fuse 10A 84°C
PTI	175
Cooling Condition	Not required forced cooling
Type of Connection and Load	Single Pole Single Load (single pole disconnection)
Test Condition	Maximum rated resistive current

Do not connect after each other.

Not to be used in direct sunlight.

CE

Download complete technical manual and find more useful information at **telldus.com**

Ladda ner fullständig teknisk manual och hitta mer nyttig information på **telldus.com**

Last ned den komplette tekniske håndboken og finn mer nyttig informasjon på **telldus.com**

Laden Sie das vollständige technische Handbuch herunter und finden Sie weitere nützliche Informationen unter **telldus.com**

Lataa kattava tekninen opas ja katso lisätietoja seuraavasta osoitteesta **telldus.com**

Download den fulde tekniske vejledning, og find mere nyttig information på **telldus.com**

facebook.com/telldus

@telldus

Telldus is marketed by Proove AB
Kabelvägen 7, 311 50 Falkenberg, Sweden
www.proove.se • +46 (0)346 715600

1.1

CONNECTING YOU AND YOUR HOME