

LEDDim Smart Pill



220-240V, 50/60Hz, -20°C to 35°C

<p>INDEPENDENT</p> <p>EN: Push button (optional) FR: Bouton-poussoir (optionnel) DE: Druckknopf (optional)</p> <p>0-1s </p> <p>>1s </p>	<p>BUILT-IN</p> <p>EN: Push button (optional) FR: Bouton-poussoir (optionnel) DE: Druckknopf (optional)</p> <p>0-1s </p> <p>>1s </p>								
<table border="1"> <tr> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>Max. 200W</td> <td>Max. 160W</td> <td>Max. 160W</td> <td></td> </tr> </table> <p> </p> <p> </p> <p> </p>					Max. 200W	Max. 160W	Max. 160W		<p>EN: Minimum dimming level adjustment FR: Réglage du niveau de gradation minimal DE: Anpassung der minimalen Dimmstufe</p> <p>Reset / Réinitialiser / Zurücksetzen</p>
Max. 200W	Max. 160W	Max. 160W							
<p> NO: Kan kun installeres av en registrert installasjonsvirksomhet. EN: Only to be installed by an authorized electrician. FR: Doit être installé par un électricien autorisé. NL: Mag alleen geïnstalleerd worden door een bevoegde elektricien. DE: Dieses Produkt darf nur durch autorisiertes Personal (z. B. Elektro-Installateur) angeschlossen und in Betrieb genommen werden. FI: Asentaa saa vain valtuutettu sähköasentaja</p>	<p> NO: Skru av strømmen før montering. EN: Turn off power before installing. FR: Couper le courant avant l'installation. NL: Stroom uitschakelen voor u het toestel installeert. DE: Vor Installationsarbeiten den Strom abschalten. FI: Sammuta virta ennen kytkemistä</p>								

NORWAY SG Armaturen AS
Tlf:+47 37 50 03 00
firmapost@sg-as.no
www.sg-as.no

SWEDEN SG Armaturen AB
Tel: +46 31 81 71 10
info@sg-ab.se
www.sg-ab.se

FRANCE SG Lighting SA/NV
Tel: +33(0) 4 94 93 00 00
info.france@silighting.fr
www.silighting.net

GERMANY SG Leuchten GmbH
Tel: +49 40 23 99 44 59
info@sg-leuchten.de
www.sg-leuchten.de

DENMARK SG Armaturen A/S
Tel: +45 70 70 72 13
info@sg-as.dk
www.sg-as.dk

FINLAND SG Armaturen Oy
info@sg-oy.fi
www.sg-oy.fi

BENELUX SG Lighting SA/NV
Tel: +32(0) 15 20 72 71
info.benelux@silighting.net
www.silighting.net

INTERNATIONAL SG Lighting Co Ltd.
Tel: +86 769 88 49 20 88
cindy@sgdgc.com
www.sg-as.com

LEDDIM APP



ANDROID
Android OS 5.1
Ram 2.5GB
mid-range CPUs<




IOS
IOS 9.0
iPhone 5s<

<http://www.sg-as.no/leddim/getapp/>


LEDDIM Guide



<http://www.sg-as.no/leddim/>







Range






Mesh grid function

IOS LEDDIM Guide






1. REGISTER create account



2. LOCATION create location




3. MANAGE DEVICE add dimmers



4. GROUP
create group






5. LOCATION
Share location









ANDROID LEDDIM Guide





1. REGISTER create account







2. LOCATION create location



3. MANAGE DEVICE add dimmers



4. GROUP create group



5. LOCATION Share location

